

Boat Alarm



Monitor your boat position and log, Email/IM alarm, and sound alarm and it monitors the device's current location and informs you if the location of the device changes too far away from the set anchor



Application features:

Shows GPS location and accuracy

Monitors current distance to the anchor

Alerts you in case you drift too far from the anchor


Alerts you in case you lose GPS signal


Allows you to select a sound alarm

Allows setting exclusion zones

Uses the device's compass to set the anchor even if you are not located directly above it











Basic License:

Sound alarm.

Track position.

Exclusion zones.

Export log to xls



Premium License:

Define a hexagonal and editable wetting zone on the screen.

Send a mail when an alarm is raised.

View SailGrib WR maps.

Import the GPX trace of SailGrib WR.